


Set using ISO screws



SPECIFICATIONS

TV-signal Standards: American TV-standard

> Picture Tube: 5" (measured diagonally), 70°

> > deflection aluminized screen

140CB4

Semiconductors: 23 transistors and 14 diodes

Channel Coverage: VHF; ch. A2-A13

UHF; ch. A14-A83

Antenna System: Built-in telescopic antenna

Terminals for 75-ohm external

antenna

VHF; Disc turret type Tuner System:

UHF; Continuous tuning type

VIF Circuit: 3 stages with 4 stagger tuned

element

Picture i-f carrier; 45.75 MHz

Sound i-f carrier; 41,25 MHz

Sound System: 4.5 MHz intercarrier system

Power output stage; OTL system 350 mW

Speaker; 23/4" (7 cm), 40 ohms

Automatic Control Systems:

Forward agc Single pulse afc

Power Requirements:

AC 117V, 60 Hz

DC 12V

Power Consumption:

AC 13W (maximum) DC 8.6W (maximum)

Dimensions: $8\frac{3}{4}$ " (W) x 7" (H) x $8\frac{7}{8}$ " (D)

(223 mm x 178 mm x 225 mm)

Weight: 7 lb 8 oz (3.4 kg)






TABLE OF CONTENTS


	<u>Title</u> <u>Pa</u>			<u>Title</u>	Page
1.	OUTLINE			ower Supply Circuit Board (P)	• .
	1-1. Block Diagram	. 2		- Component Side	16
	1-2. External View		4-5. So	ound Circuit Board (S)	
	1-3. Internal View	_		- Conductor Side	17
	1 3. Internal view		4-6. So	ound Circuit Board (S)	
2.	. DISASSEMBLY			- Component Side	17
	2-1. Rear Cabinet Removal	. 4	4-7. Se	ound Circuit Board (S)	
	2-2. Circuit Board Removal			(Schematic Diagram)	18
	2-3. Protector Removal		4-8. Si	ignal Circuit Board (BC)	
	2-4. Front Cabinet Removal			(Schematic Diagram)	19
	2-5. Speaker Removal		4-9. S	ignal Circuit Board (BC)	
	2-6. High Voltage Block Removal			- Conductor Side	21
	2-7. Picture Tube Removal		4-10. S	ignal Circuit Board (BC)	
	2-8. Volume and Contrast Controls	. ,		- Component Side	22
	Removal	. 8	4-11. D	eflection Circuit Board (EF)	
	2-9. Vertical Hold and Brightness	. 0		(Schematic Diagram)	23
		. 8	4-12 D	eflection Circuit Board (EF)	
	Controls Removal2-10. Tuner Block Removal			- Conductor Side	25
	2-10. Tullet block Removal	., 0	4-13. W	/aveforms	26
3	. CIRCUIT ADJUSTMENT		4-14. D	Deflection Circuit Board (EF)	
	3-1. VIF Adjustments	10		- Component Side	27
	3-2. SIF Adjustments	. 12	4-15. S	chematic Diagram	
	3-3. Deflection Circuit Adjustments			•	
	•		5. EXPLOI	DED VIEW AND PACKING	
4	SCHEMATIC AND MOUNTING		5-1. E	xploded View (1)	. 31
	DIAGRAMS			xploded View (2)	
	4-1. VHF Tuner (Schematic Diagram)	15	5-3. P	acking	. 34
	4-2. VHF Tuner (Mounting Diagram)			RICAL PARTS LIST	
	4-3. Power Supply Circuit Board (P)				
	- Conductor Side	16	TV-510U B	SATTERY PACK BP-21	. 40

SECTION 1 OUTLINE

1-1. BLOCK DIAGRAM



1-2. EXTERNAL VIEW



1-3. INTERNAL VIEW





Fig. 1-3

Fig. 1-4

SECTION 2 DISASSEMBLY

2-1. REAR CABINET REMOVAL

- Remove the five screws labeled A1-A5 in Fig. 2-1.
- Take off the rear cabinet.



2-2. CIRCUIT BOARD REMOVAL

Remove the rear cabinet to perform the following steps:

Sound Board (S)

- 1. Remove the two screws labeled B1 and B2 in
- 2. Pull out the S-board in the direction shown by the arrow in Fig. 2-2.
- 3. Unsolder the four PVC leads and one shielded cable illustrated in Fig. 2-3.




Fig. 2-2

Signal Board (BC)

- 1. Remove the three screws labeled C1-C3 in Fig. 2-4.
- Take off the BC board as shown in Fig. 2-4.






Fig. 2-4





Power Board (P)

- 1. Remove a screw labeled D1 in Fig. 2-6.
- 2. Unsolder the two terminals of a electrolytic capacitor labeled E1 in Fig. 2-6 and then lift off the P board.




Fig. 2-6





Fig. 2-7

Deflection Board (EF)

- 1. Remove the four screws labeled F1-F4 in Fig. 2-8.
- 2. Pull up the EF board as shown in Fig. 2-8.
- 3. Pull off the seven pin-plugs labeled G1-G7 in Fig. 2-9.
- 4. Turn the EF board in the direction shown by the arrow in Fig. 2-8.






Fig. 2-9

2-3. PROTECTOR REMOVAL

- 1. Pull off four front-panel knobs as shown in Fig. 2-10.
- 2. Remove the two screws labeled H1 and H2 in Fig. 2-10.
- 3. Remove the protector.




Fig. 2-10

2-4. FRONT CABINET REMOVAL

- 1. Remove the rear cabinet and protector.
- 2. Remove the screw labeled J1 in Fig. 2-11.
- 3. Remove the two screws labeled K1 and K2 in Fig. 2-12.




Fig. 2-11





Fig. 2-12

- Remove the four screws labeled L1-L4 in Figs. 2-13 and 2-14.
- 5. Remove the S board.
- 6. Pull off the picture tube socket shown in Fig. 2-15.
- 7. Remove the anode cap shown in Fig. 2-15.
- 8. Unsolder the two grounding-wires shown in Fig. 2-15.
- 9. Remove the front cabinet with picture tube from the chassis carefully.






Fig. 2-14




Fig. 2-15

2-5. SPEAKER REMOVAL

- 1 Remove the rear cabinet.
- 2. Remove the two screws labeled M1 and M2 in Fig. 2-16.
- 3. Unsolder the two leads on the speaker terminals.
- 4. Replace the speaker carefully.




Fig. 2-16

2-6. HIGH VOLTAGE BLOCK REMOVAL

- 1. Remove the rear cabinet and EF board.
- 2. Remove the two screws labeled N1 and N2 in Fig. 2-17.




Fig. 2-17




Fig. 2-18

- 3. Unsolder the four lead-wires on the EF board labeled P1-P4 in Fig. 2-18.
- 4. Pull out the three pin-plugs on the EF board labeled P5-P7 in Fig. 2-18.

2-7. PICTURE TUBE REMOVAL

- 1. Remove the rear cabinet and protector.
- 2. Remove the BC circuit board. (See Procedure 2-2).
- 3. Loosen a screw labeled Q1 in Fig. 2-19.
- 4. Remove the front cabinet.
- 5. Pull out the deflection yoke.
- 6. Remove the four screws labeled R1-R4 in Fig. 2-20.
- 7. Loosen a screw labeled S1 in Fig. 2-20.




Fig. 2-19





Fig. 2-20

2-8. VOLUME AND CONTRAST CONTROLS REMOVAL

- 1. Remove the protector.
- 2. Remove the two screws labeled T1 and T2 in Fig. 2-21.
- 3. Pull out the volume and contrast controls as shown in Fig. 2-23.



2-9. VERTICAL HOLD AND BRIGHTNESS CONTROLS REMOVAL

- 1. Remove the protector.
- 2. Remove the volume and contrast controls.
- 3. Remove a screw labeled U1 in Fig. 2-22.
- 4. Pull out the vertical hold and brightness controls as shown in Fig. 2-23.




Fig. 2-22






Fig. 2-23





2-10. TUNER BLOCK REMOVAL

VHF Tuner Removal

- 1. Remove the rear cabinet and protector.
- 2. Remove the front cabinet.
- 3. Remove the two screws labeled V1 and V2 in Fig. 2-25.
- 4. Push the tuner toward the power transformer and lift it up.







- 1. Remove the rear cabinet and protector.
- 2. Remove the front cabinet and VHF tuner.
- 3. Remove the two screws labeled W1 and W2 in Fig. 2-27.
- 4. Loosen a nut labeled X1 in Fig. 2-28.
- 5. Take off the UHF tuner carefully.






Fig. 2-27



to U-V separator



— 9 —



SECTION 3 CIRCUIT ADJUSTMENT

3-1. VIF ADJUSTMENTS


Equipment Required:

Sweep generator – covering the range of $39 \sim 48$ MHz Signal generator – covering the range of $33 \sim 35$ MHz Marker generator – covering the range of $39 \sim$ 48 MHz

 $\begin{aligned} &Rheostat - 250\,k \text{ ohm} \\ &Oscilloscope} \\ &VOM \end{aligned}$

Preparations:

- 1. Set the channel selector to the highest inactive channel in the area.
- 2. Unsolder the keying-pulse lead.
- 3. Connect a scope to the VIF output terminals through a noise filter consisting of a 10-k ohm resistor and a 300-pF capacitor as shown in Fig. 3-1.



39.75 MHz, 41.25 MHz and 47.25 MHz Trap Adjustments

- 1. Connect the VIF INPUT cable.
- 2. Connect a sweep generator to the tuner's test point through a 0.01- μ F capacitor as shown in Fig. 3-2.
- 3. Loosely couple a marker generator to the output lead of the sweep generator.
- 4. Make the adjustments specified in TABLE 3-1 to produce the trap response curve as shown in Fig. 3-3.





Fig. 3-2



33.75 MHz Trap Adjustments

- 1. Unsolder the VIF INPUT cable.
- 2. Connect a signal generator (33.75 MHz with 1 kHz 40% AM modulation) to the point where the VIF INPUT cable was connected as shown in Fig. 3-1.
- Adjust the core of L304 for minimum 33.75 MHz modulated waveform on the scope.
- 4. Disconnect the signal generator.

VIF Response Curve Adjustments

- 1. Unsolder the VIF INPUT cable.
- 2. Connect a 250-k ohm rheostat across a resistor R326 as shown in Fig. 3-4.
- 3. Connect a VOM between the emitter of Q301 and grounding point as shown in Fig. 3-4.
- 4. Set the 250-k ohm rheostat to indicate 1.35 to 1.5 V on the VOM.

- 5. Disconnect the VOM.
- 6. Connect the VIF INPUT cable.
- 7. Connect a sweep generator and a marker generator to the tuner's test point as shown in Fig. 3-2.
- 8. Connect a scope to the VIF output terminals through a noise filter as shown in Fig. 3-1.
- 9. Set the marker generator to produce 44 MHz marker signal.
- 10. Adjust the output of sweep generator so that the 44 MHz marker on the VIF response curve indicates 15.5 Vp-p on the scope as shown in Fig. 3-5.
- 11. Make the adjustments specified in TABLE 3-2 to produce the VIF response curve as shown in Fig. 3-5.
- 12. Adjust the coil L207 in the tuner when satisfactory VIF response curve is not obtain by the foregoing Procedures.
- 13. Disconnect the sweep generator and scope.
- 14. Resolder the keying-pulse lead.




Fig. 3-4




Fig. 3-5

TABLE 3-1. VIF TRAP ADJUSTMENTS

Marker Freq.	Adjust	Remarks
39.75 MHz	L303	Adjust the coil for minimum indication on the scope.
41.25 MHz	L301	Same as above.
47.25 MHz	L302	Same as above.

TABLE 3-2. VIF RESPONSE CURVE ADJUSTMENTS

Marker Freq.	Adjust	Remarks
44.0 MHz	T302 (pink core)	Adjust T302 for maximum distance between the marker point and baseline.
44.0 MHz	T303 (blue core)	Adjust T303 for maximum distance between the marker point and baseline.



3-2. SIF ADJUSTMENTS

Equipment Required:

Signal generator - 4.5 MHz with 1,000 Hz AM modulation

Sweep generator — covering the range 4 to 5 MHz Marker generator — covering the range 4 to 5 MHz Oscilloscope

Rheostat - 250-k ohm

Procedure:

- 1. Unsolder the VIF INPUT cable.
- 2. Connect the 250-k ohm rheostat across resistor R326 as shown in Fig. 3-4.
- 3. Set the 250-k ohm rheostat to make all video noise disappear from the screen of picture tube. (blank raster)

- 4. Connect a signal generator to the video-detector output as shown in Fig. 3-6.
- 5. Set the brightness control for optimum brightness and the contrast control fully clockwise position.
- 6. Adjust coil L402 for minimum 4.5 MHz stripes in the picture as shown in Fig. 3-7.
- 7. Disconnect the signal generator.
- 8. Connect a sweep generator to the videodetector output as shown in Fig. 3-6.
- 9. Loosely couple a marker generator to the output lead of the sweep generator.
- 10. Unsolder the SIF output cable.
- 11. Connect a dummy resistor (5-k ohm) across the input terminals of scope as shown in Fig. 3-8.
- 12. Connect a scope to the SIF output terminals (C420) as shown in Fig. 3-8, then make the adjustments specified in the following TABLE 3-3.

TABLE 3-3. SIF ADJUSTMENTS

Marker Freq.	Adjust	Remarks
4.5 MHz T401 T402		Turn up sweep output signal to produce an S curve. Adjust T401 and T402 for maximum deflection on the scope.
4.5 MHz	T403 (pink core)	Turn the core to make the S curve symmetrical.
4.5 MHz	T403 (blue core)	Turn the core to cross the baseline at 4.5 MHz on the S curve.

Note: Repeat the above steps as necessary to produce the waveform as shown in Fig. 3-9.




Fig. 3-6




Fig. 3-9 SIF adjustment curve





Fig. 3-8

V-510U

3-3. DEFLECTION CIRCUIT ADJUSTMENTS


Step	Adjustment for	Preliminary Instruction	Equipment	Connection	Adjust	Remarks
. 1	Collector current of Q501 (VIDEO OUT)	Set the tuner to an inactive channel. Check 12V and 50V (across C504) power supply.	VOM	Across R504	R502 (43k – 68k)	For approx. 16 – 18 V reading.
2	Collector current of Q703 (VER OUT)	Adjust V and H hold controls for correct sync. Check 12V power supply.	VOM	Across R714	R711 (1600 – 2200)	For approx. 0.32 - 0.33 V reading.
3	Vert. Height and Linearity	Receive a test pattern. Check 12V power supply.			VR702 (Vert. Height) VR703 (Vert. Linearity)	For optimum vertical height and linearity on the picture.
4	Pulse width	Adjust V and H hold controls for correct sync.	scope	Emitter of Q801	C804 (0.047 – 0.22 μF)	For 8.5 – 9.0 V used in Fig. 3 – 10.
5	HSC (Hor. stabilizing coil)	Adjust V and H hold controls for correct sync. Receive a test pattern.			HSC	So that the picture is stable in either case whether HSC is shorted or normal.
6	Horizontal width	Adjust V and H hold controls for correct sync. Set the brightness control to optimum position.	scope		C808 (0 – 0.015 μF)	For optimum picture width.
7	Focus	Same as above. Adjust V and H hold controls for correct sync.			VR801 (600k ohm)	To obtain best focus.






SECTION 4 SCHEMATIC AND MOUNTING DIAGRAMS

4-1. VHF TUNER



42. VHF TUNER


MOUNTING DIAGRAM




Note:

- 1. Voltages measured from chassis to point indicated with a VOM (20k ohm/V) with no signal input.
- 2. The components are subject to change without notice.
- 3. The following components are mounted on the conductor side. (Q201, Q202, Q203, L202, L203, L208, L211, L216, R213, C207)

4-3. POWER SUPPLY CIRCUIT BOARD (P)






- Note:
- 1. All capacitors are 50WV unless otherwise specified.
- 2. All resistors are ¼W unless otherwise specified.
- 3. Voltages measured from chassis to point indicated with a VOM (20k ohm/V) with no signal input.
- 4. The components are subject to change without notice.
- 5. White lettering numbers in the black circle indicate the lead connecting points, and alphabet marks indicate the printed circuit board.
 - Example: BC 2; Connect to the number 2 of BC board.

TV-510U TV-510U


4-5. SOUND CIRCUIT BOARD (S) MOUNTING DIAGRAM

- Conductor Side -



46. SOUND CIRCUIT BOARD (S) MOUNTING DIAGRAM

- Component Side -



TRANSISTORS


Q551	2SC633A
Q552	2SB383
Q553	2SD72
Q554	2SB382


Note:

- 1. All capacitors are 50WV unless otherwise specified.
- 2. All resistors are ¼W unless otherwise specified.
- 3. Voltages measured from chassis to point indicated with a VOM (20k ohm/V) with no signal input.
- 4. The components are subject to change without notice.
- 5. White lettering numbers in the black circle indicate the lead connecting points, and alphabet marks indicate the printed circuit board.


Example: P 1 ; Connect to the number 1 of P board.

4-7. SOUND CIRCUIT BOARD (S) SCHEMATIC DIAGRAM





4-8. SIGNAL CIRCUIT BOARD (BC) SCHEMATIC DIAGRAM




Note:


- 1. All capacitors are 50WV unless otherwise specified.
- 2. All resistors are ¼W unless otherwise specified.
- 3. Voltages measured from chassis to point indicated with a VOM (20k ohm/V) with no signal input.
- 4. The components are subject to change without notice.

	TRAN	SISTORS			D	IODES		
Q301	2SC657	Q401	2SC403A	D301	1T261	D401	1T243	
Q302	2SC657	Q402	2SC403A	D302	1T22	D402	1T23	
Q303	2SC629	Q403	2SC403A			D403	1T23	
Q304	2SB382		•					
O305	2SB382							


4-9. SIGNAL CIRCUIT BOARD (BC) MOUNTING DIAGRAM




Q301, Q302, Q303 Q401, Q402, Q403



Q304, Q305




D301, D302, D401, D402, D403



4-10. SIGNAL CIRCUIT BOARD (BC) MOUNTING DIAGRAM

- Component Side -



	TRAN	SISTORS			D	IODES		
Q301 Q302 Q303	2SC657 2SC657 2SC629	Q401 Q402 Q403	2SC403A 2SC403A 2SC403A	D301 D302	1T261 1T22	D401 D402 D403	1T243 1T23 1T23	
Q304 Q305	2SB382 2SB382							


- All capacitors are 50 WV unless otherwise specified.
 All resistors are ¼W unless otherwise specified.
- Voltages measured from chassis to point indicated with a VOM (20k ohm/V) with no signal input.
 The components are subject to change without notice.
- 5. White lettering numbers in the black circle indicate the lead connecting points, and alphabet marks indicate the printed circuit board.
- Example: P 6; Connect to the number 6 of P board.

 6. The following components are mounted on the conductor side.

 (L311, C321, C335, C341, C342, R407, R412)

TV-510U TV-510U


4-11. DEFLECTION CIRCUIT BOARD (EF) SCHEMATIC DIAGRAM



TV-510U TV-510U

4-12. DEFLECTION CIRCUIT BOARD (EF) MOUNTING DIAGRAM

- Conductor Side -




	TRANSI	STORS			DI	ODES	
O501	2SC352A	Q801	2SB324	D501	1T22A	D701	1T22A
QUUI		Q802	2SC756			D702	1T22A
Q601	2SA610			D601	1T22A		
QUUI				D602	1T22A	D801	HFSD1Z
0701	2SC633A					D802	10D2
Q702	2SB382					D803	UFSD1A
0703	2SD29						

Note:


- 1. All capacitors are 50WV unless otherwise specified.
- 2. All resistors are ¼W unless otherwise specified.
- 3. Voltages measured from chassis to point indicated with a VOM (20k ohm/V) with no signal input.
- 4. The components are subject to change without notice.
- 5. White lettering numbers in the black circle indicate the lead connecting points, and alphabet marks

4-13. WAVEFORMS



4-14. DEFLECTION CIRCUIT BOARD (EF)

MOUNTING DIAGRAM



	TRANSI	ISTORS			DI	ODES	
Q501	2SC352A	Q801 Q802	2SB324 2SC756	. D501	1T22A	D701 D702	1T22A 1T22A
Q601	2SA610	Q802	250/30	D601 D602	1T22A 1T22A	D801	HFSD1Z
Q701 Q702 Q703	2SC633A 2SB382 2SD29					D802 D803	10D2 UFSD1A


Note:

- 1. All capacitors are 50WV unless otherwise specified.
- 2. All resistors are ¼W unless otherwise specified.
- 3. Voltages measured from chassis to point indicated with a VOM (20k ohm/V) with no signal input.
- 4. The components are subject to change without notice.
- 5. White lettering numbers in the black circle indicate the lead connection points, and alphabet marks indicate the printed circuit board.

 Example: BC ; Connect to the number 9 of BC board.


 6. The following component is mounted on the conductor side.

 (R102)



TV-510U TV-510U


4-15. SCHEMATIC DIAGRAM




Note:

- 1. All capacitors are 50WV unless otherwise specified.
- 2. All resistors are ¼W unless otherwise specified.
- 3. Resistance and capacitance values marked Δ are to be selected to yield specified operating conditions.
- 4. Voltages measured from chassis to point indicated with a VOM (20k ohm/V) with no signal input.
- 5. The components are subject to change without notice.


SECTION 5 EXPLODED VIEW AND PACKING







5-3. PACKING





SECTION 6 ELECTRICAL PARTS LIST

Ref. No.	Part No.	<u>L</u>	escription	Ref. No.	Part No.	Desc	eription
		GENERAL		D901		diode	10D2
	98-0132-15 VHF tuner ass'y (BT-443Wu)		ass'v (BT-443W11)	D902		diode	10D2
	1-463-008		ass'y (BT-181)	D902		diode	10D2
	98-0140-25		board (BC), complete	D 703		diode	1002
	98-0168-35	ū	rcuit board (EF), complete	Th301	8-690-003-00	thermistor	S90
	98-0168-45		t board (S), complete	Th302	8-690-006-00	thermistor	S1250
	98-0168-55		y circuit board (P), complete	111302	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	mornistoi	51230
	70 0100 35	power suppr	y on our court (x), comprete	Th551	8-691-001	thermistor	CS-120
	SEMI	CONDUCTOR	S	}	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	***************************************	35 120
Q301		transistor	2SC657			COILS	
Q302		transistor	2SC657	L7	1-407-178	1μΗ	micro inductor
Q303		transistor	2SC629				
Q304		transistor	2SB382	L301	1-409-160-31	41.25 MHz	trap coil
Q305		transistor	2SB382	L302	1-409-160-21	47.25 MHz	trap coil
				L303	1-409-160-21	39.75 MHz	trap coil
Q401		transistor	2SC403A	L304	1-409-170-11	33.75 MHz	trap coil
Q402		transistor	2SC403A	L305	1-407-178	1 μΗ	micro inductor
Q403		transistor	2SC403A	L306	1-407-178	1 μΗ	micro inductor
				L307	1-407-157	10μΗ	micro inductor
Q501		transistor	2SC352A	L308	1-407-184	$3.3 \mu\text{H}$	micro inductor
				L309	1-407-173	220 µH	micro inductor
Q551		transistor	2SC633A	L310	1-407-184	3.3 µH	micro inductor
Q552		transistor	2SB383	L311	1-407-178	1 μΗ	micro inductor
Q553		transistor	2SD72				
Q554		transistor	2SB382	L401	1-407-178	$1 \mu H$	micro inductor
				L402	1-409-036-11	4.5 MHz	trap coil
Q601		transistor	2SA610	L403	1-407-187	5.6 μΗ	micro inductor
Q701		transistor	2SC633A	L501	1-407-172	180 µH	micro inductor
Q702		transistor	2SB382				,
Q703		transistor	2SD29	L601	1-407-165	47 μH	micro inductor
Q801		transistor	2SB324	L701	1-421-127	choke coil,	vertical output
Q802		transistor	2SC756	7.001	1 401 010 11	25 11	
D201		11. 1.	ITT3 (1	L801	1-421-013-11	25 μΗ	filter inductor
D301		diode	IT261	L803	1-413-012-12	con, norizo	ntal stabilizing
D302		diode	IT22	1001	1 421 150 12	files abales	
D401		diada	IT243	L901	1-421-150-12	miter choke	coil, power rectifier
D401 D402		diode diode	IT23		TD.	NEEODMED	.00
D402 D403		diode	IT23	T302	1-403-701	ANSFORMER VIFT	
D403		aiode	1123	T302	1-403-701	VIFT	
D501		diode	IT22A	1303	1 103 702	V11 1	
2002				T401	1-403-348	SIFT	
D601		diode	IT22A	T402	1-403-349	SIFT	
D602		diode	IT22A	T403	1-403-313	SIFT	
D701		diode	IT22A	T701	1-435-008-12	transform -	r, vertical osc; VBT
D701 D702		diode	IT22A IT22A	T701	(1-435-008-12		r, vertical osc; VBT
D102		ulouc	11227	T801	1-435-006-11		r, horizontal osc; HBT
D801		diode	HFSD1Z	T802	1-437-004-11		r, horizontal drive; HDT
D801 D802		diode	10D2	T803	1-453-625		e cage block; HOT
D802 D803		diode	UFSD1A	T901	1-433-623		r, power; PT
נטסע		ulouc	OUBDIA	1 1701	1-7-1-010	tiansionile.	ı, power, r ı

V-510U

Ref. No.	Part No.	Description	· Ĺ	Ref. No.	Part No.		Description
	CA	PACITORS		C416	1-101-423	500pF	±20% 50WV ceramic
C301	1-101-957		WV ceramic	C417	1-121-398	-	$\pm^{100}_{0}\%$ 25WV electrolytic
C302	1-101-969		WV ceramic	C418	1-101-118	$0.01 \mu F$	±20% 50WV ceramic
C303	1-101-969	5pF ±0.5% 50	WV ceramic	C419	1-101-118	$0.01 \mu \mathrm{F}$	±20% 50WV ceramic
C304	1-101-832	9pF ±0.2pF 50	WV ceramic	C420	1-101-002	$0.002 \mu F$	$\pm^{100}_{0}\%$ 50WV ceramic
C305	1-101-583	60pF ±5% 50	WV ceramic	C422	1-101-006	$0.04 \mu F$	$\pm^{100}_{0}\%$ 50WV ceramic
C306	1-101-057	80pF ±5% 50	WV ceramic	C423	1-101-003		$\pm {}^{100}_{0}\%$ 50WV ceramic
C307	1-101-892	•	WV ceramic	C424	1-121-358	$220\mu F$	± ¹⁰⁰ % 16WV electrolytic
C308	1-101-003		WV ceramic				
C309	1-101-003	· · · · · ·	WV ceramic	C501	1-121-469	$10\mu F$	$\pm^{100}_{0}\%$ 10WV electrolytic
C310	1-101-961		WV ceramic	C502	1-102-834	390pF	±10% 50WV ceramic
C311	1-101-003		WV ceramic	C503	1-113-124	$0.2\mu F$	±10% 150WV paper
C312	1-101-455		WV ceramic	C504	1-121-246		$\pm^{100}_{0}\%$ 160WV electrolytic
C313	1-101-003		WV ceramic	C505	1-113-122	$0.05\mu F$	±20% 500WV paper
C314	1-101-961		WV ceramic	C506	1-121-415		$\pm {}^{100}_{0}\%$ 16WV electrolytic
C315	1-101-003	400	WV ceramic	C507	1-121-398		$\pm {}^{100}_{0}\%$ 25WV electrolytic
C316	1-101-003		WV ceramic	C551	1-121-398		$\pm {}^{100}_{0}\%$ 25WV electrolytic
C317 C318	1-101-455 1-101-940	•	WV ceramic WV ceramic	C552	1-121-421		$\pm {}^{100}_{0}\%$ 16WV electrolytic $\pm {}^{100}_{0}\%$ 10WV electrolytic
C318	1-101-940	- 100	WV ceramic	C553 C554	1-121-402 1-121-421		$\pm {}^{100}_{0}\%$ 10WV electrolytic $\pm {}^{100}_{0}\%$ 16WV electrolytic
C320	1-101-003	400	WV electrolytic	C555	1-121-421		$\pm {}^{100}_{0}\%$ 16WV electrolytic
C321	1-101-003	100	WV ceramic	C556	1-121-409	$0.022 \mu F$	$\pm 10\%$ 100WV mylar
C323	1-101-003	100	WV ceramic	C557	1-105-717-12	0.022μΓ 0.022μF	±10% 100WV mylar
C324	1-101-587		WV ceramic	C558	1-127-019		% 10WV electrolytic (alox)
C327	1-101-955		WV ceramic	-	112, 019	0.1 µ 1 –20	70 Ton V electrony the (allow)
C328	1-101-003	$0.005\mu F \pm \frac{100}{0}\%$ 50	WV ceramic	C602	1-127-094	1μF ±20	% 25WV electrolytic (alox)
C329	1-121-402	$33\mu F$ $\pm \frac{100}{0}\%$ 10	WV electrolytic	C603	1-105-715-12	0.015µF	±10% 100WV mylar
C330	1-101-006	100)WV ceramic	C604	1-105-711-12	$0.0068 \mu F$	±10% 100WV mylar
C331	1-127-023	1μF ±20% 10WV alum	ninum electrolytic	C605	1-105-721-12	$0.047 \mu F$	±10% 100WV mylar
C332	1-105-669-12	•)WV mylar	C606	1-121-415	100μF	$\pm^{100}_{0}\%$ 16WV electrolytic
C333	1-127-024	2.2μF ±20% 10WV alu	ıminum electrolytic	C607	1-121-396	4.7μF	±100 % 50WV electrolytic
C334	1-101-958	• •)WV ceramic	C608	1-127-091	$0.22 \mu F \pm 2$	0% 25WV electrolytic (alox)
	1-101-837)WV ceramic	C609	1-105-721-12	$0.047\mu F$	±10% 100WV mylar
* C335 {	1-101-586)WV ceramic	C610	1-105-717-12	$0.022\mu F$	±10% 100WV mylar
C225	1-101-163	•)WV ceramic	C611	1-121-393	3.3μF	$\pm {}^{100}_{0}\%$ 50WV electrolytic
C337	1-127-022	$0.47\mu\text{F} \pm 20\% 10\text{WV al}$	Į.			4	
C341 C342	1-101-455		OWV ceramic	C701	1-127-232		% 25WV electrolytic (alox)
C342	1-101-969	5pF ±0.5pF 50	OWV ceramic	C702	1-131-116	10μF	±20% 16WV electrolytic
C401	1-103-610	240pF ±5% 50	OWV polystyrene	C703 C704	1-121-398		$\pm^{100}_{0}\%$ 50WV electrolytic
C402	1-103-663	-	OWV polystyrene	C704	1-127-231 1-121-420	3.3μF ±20 220μF	% 25WV electrolytic (alox) $\pm {}^{100}_{0}$ % 10WV electrolytic
C403	1-101-896	. =	OWV ceramic	C706	1-121-426	220μF 470μF	$\pm \frac{100}{0}\%$ 16WV electrolytic
C404	1-101-004	- 400	OWV ceramic	C707	1-121-420	470μΓ 0.15μF	±10% 100WV mylar
C405	1-101-956		OWV ceramic	C709	1-105-713-12	0.13μt 0.01μF	±10% 100WV mylar
C406	1-101-004	100	OWV ceramic	0,00	1 103 /13 12	0,0141	=10% 100W V IIIylai
C408	1-101-004	100	OWV ceramic	C801	1-105-715-12	0.015μF	±10% 100WV mylar
C409	1-101-455		OWV ceramic	C802	1-105-723-12	0.068µF	±10% 100WV mylar
C410	1-101-958	•	OWV ceramic	C803	1-105-729-12	0.22μF	±10% 100WV mylar
. C411	1-101-004	$0.01\mu F \pm \frac{100}{0}\%$ 50	OWV ceramic	,	1-105-721-12	0.047µF	±10% 100WV mylar
C412	1-101-006	$0.04 \mu F$ $\pm \frac{100}{0}\%$ 50	0WV ceramic	∜C804	1-105-725-12	0.1μF	±10% 100WV mylar
C413	1-101-115	30pF ±5% 50	0WV ceramic	1	1-105-727-12	0.15µF	±10% 100WV mylar
C414	1-101-571		OWV ceramic	'	1-105-729-12	$0.22\mu F$	±10% 100WV mylar
C415	1-101-423	500pF ±20% 50	OWV ceramic	C805	1-105-725-12	$0.1 \mu F$	±10% 100WV mylar

*: to be selected

Ref. No.	Part No.		Description	1	1	Ref. No.	Part No.		Desc	ription	
C806	1-121-421	220µF	±100% 10	swv	electrolytic	R328	1-248-655	180Ω	±10%	ERD14V	carbon
C807	1-105-292-12	0.055μF	±10% 250			R329	1-248-665	470Ω		ERD14V	
C808	1-105-274-12		0.005μF 20		٠	R330	1-248-683	2,700Ω		ERD14V	
C809	1-105-753-12	0.01µF	±10% 10		, ,	R331	1-248-671	820Ω		ERD14V	
C811	1-113-122	0.05µF	±20% 50		· ·	R332	1-248-657	220Ω		ERD14V	
C812	1-113-122	0.05µF	±20% 50				(1-248-703	18kΩ		ERD14V	
C813	1-113-122	0.05µF	±20% 50			3 R333	1-248-704	20kΩ		ERD14V	
C814	1-113-122	0.05µF	±20% 50				1-248-705	$22k\Omega$		ERD14V	
C818	1-101-845	1,000pF	±100 50				1-248-706	$24k\Omega$	±5%	ERD14V	carbon
C819	1-101-455	1,000pF			ceramic	R334	1-248-666	510Ω	±10%	ERD14V	carbon
						R335	1-248-666	510Ω	±10%	ERD14V	carbon
C901	1-121-555	4,000μF	±100 1	5WV	electrolytic						
C902	1-119-106	$100 \mu F$	±20% 1	6WV	electrolytic	R401	1-248-657	220Ω	±5%	ERD14V	carbon
C903	1-121-555	$4,000 \mu F$		5WV	electrolytic	R402	1-248-664	430Ω	±5%	ERD14V	carbon
C904	1-101-003	$0.005 \mu F$	-	0WV	ceramic	R403	1-248-706	24kΩ	±10%	ERD14V	carbon
C905	1-101-003	$0.005 \mu F$	$\pm^{100}\%$ 5	0WV	ceramic	R404	1-248-686	$3,600\Omega$	±10%	ERD14V	carbon
						R405	1-248-673	1kΩ	±10%	ERD14V	carbon
	,	DE CYCETO D				R406	1-248-649	100Ω	±10%	ERD14V	carbon
]	RESISTORS	S				(1-203-892	$3,600\Omega$	±5%	RD1/16L	carbon
R301	1-248-629	15Ω	±10% ERD				1-203-497	$3,900\Omega$	±5%	RD1/16L	carbon
R303	1-248-627	12Ω	±5% ERD	14V	carbon		1-203-185	$4,700\Omega$	±5%	RD1/16L	carbon
R304	1-248-649	100Ω	±10% ERD	14V	carbon	× R407	1-203-186	$5,600\Omega$	±5%	RD1/16L	carbon
R305	1-248-659	270Ω	±10% ERD	14V	carbon		1-204-345	$5,\!100\Omega$	±5%	RD1/16L	carbon
R306	1-248-657	220Ω	±10% ERD	14V	carbon		1-203-187	$6,800\Omega$	±5%	RD1/16L	carbon
R307	1-248-665	470Ω	±10% ERD	14V	carbon		1-203-189	$8,200\Omega$	±5%	RD1/16L	carbon
R308	1-248-656	200Ω	±10% ERD	14V	carbon		1-203-190	$10k\Omega$	±5%	RD1/16L	carbon
R309	1-248-657	220Ω	±10% ERD	14V	carbon	R408	1-248-694	$7,\!500\Omega$	±10%	ERD14V	carbon
R310	1-248-659	270Ω	±10% ERD	14V	carbon	R409	1-248-685	$3,300\Omega$	±10%	ERD14V	carbon
R311	1-248-658	240Ω	±10% ERD	14V	carbon	R410	1-248-670	750Ω	±10%	ERD14V	carbon
R312	1-248-653	150Ω	±10% ERD			R411	1-248-673	1kΩ		ERD14V	carbon
R313	1-248-696	$9,100\Omega$	±10% ERD			R412	1-204-345	$5,100\Omega$	±5%	RD1/16L	carbon
R314	1-248-675	$1,200\Omega$	±10% ERD			R413	1-248-649	100Ω	±10%	ERD14V	carbon
R315	1-248-651	120Ω	±10% ERD			R414	1-248-675	$1,200\Omega$	±5%	ERD14V	carbon
R316	1-246-653	150Ω	±10% ERD			R415	1-248-675	$1,200\Omega$		ERD14V	
R317	1-248-646	75Ω	±10% ERD			R416	1-248-685	$3,300\Omega$		ERD14V	
R318	1-248-680	2kΩ	±10% ERD			R417	1-248-685	$3,300\Omega$		ERD14V	
R319	1-248-655	180Ω	±10% ERD			R418	1-248-641	47Ω		ERD14V	
R320	1-248-690	•	±10% ERD			R419	1-248-715	56kΩ		ERD14V	
R321	1-248-681	,	±10% ERD			R420	1-248-673	1kΩ	±10%	ERD14V	carbon
R322	1-248-671	820Ω	±10% ERD			D # 04	1 244 405	401 -	Lear		_
R323	1-248-687	,	±10% ERI			R501	1-246-697	10kΩ		ERD14T	
R324	1-248-665	470Ω	±5% ERD ±10% ERD				1-246-712	43kΩ		ERD14T	
R325	1-246-677 (1-248-706	,				D 502	1-246-713	47kΩ		ERD14T	
		24kΩ	±5% ERI ±5% ERI			× R502	1-246-714	51kΩ		ERD14T	
	1-248-707 1-248-708	27kΩ 30kΩ	±5% ERI				1-246-715	56kΩ		ERD14T	
	1-248-710	36kΩ	±5% ERI				1-246-716 1-246-717	62kΩ 68kΩ		ERD14T ERD14T	
× R326	1-248-710	39kΩ	±5% ERI			R503	1-246-651	120Ω		ERD14T	
A N320	1-248-711	43kΩ	±5% ERI			R504	1-246-690	5,100Ω		ERD141 ERD14T	
	1-248-713	47kΩ	±5% ERI			R506	1-246-725	3,10032 150kΩ		ERD141 ERD14T	
	1-248-713	51kΩ	±5% ERI			R507	1-246-679	1,800Ω		ERD14T	
	1-248-715	56kΩ	±5% ERI			R509	1-246-714	1,80032 51kΩ		ERD14T	
R327	1-248-700	13kΩ	±5% ERI			R551	1-246-697	10kΩ		ERD14T	
102/	12.5700	121101	_5,0 DKI		Jan 0 711	, 1001	1 #70-071	10836	-5/0	-ND171	caroon

 \times : to be selected

V-510U

Ref. No.	Part No.		Description	ı	Ref. No.	Part No.	<u>Description</u>
R552	1-246-697	10kΩ	±5% ERD14T	carbon	R804	1-246-662	360Ω ±5% ERD14T carbon
R553	1-246-679		±5% ERD14T	carbon	R806	1-246-697	10kΩ ±5% ERD14T carbon
R554	1-246-612		±5% ERD14T	carbon	R807	1-246-691	5,600Ω ±5% ERD14T carbon
R555	1-246-673	$6,800\Omega$	±5% ERD14T	carbon	R808	1-246-694	7,500Ω ±5% ERD14T carbon
R556	1-246-675		±5% ERD14T	carbon	R811	1-202-621	100kΩ ±10% RC½ composition
R557	1-246-641	•	±5% ERD14T	carbon	R812	1-202-621	100kΩ ±10% RC½ composition
R558	1-246-655	180Ω	±5% ERD14T	carbon	R813	1-202-649	1.5MΩ ±10% RC½ composition
R559	1-246-659	270Ω	±5% ERD14T	carbon	R814	1-246-732	300kΩ ±5% ERD14T carbon
R560	1-246-675	$1,200\Omega$	±5% ERD14T	carbon			
R561	1-246-612	3Ω	±5% ERD14T	carbon	R901	1-201-676	750kΩ ±10% RC ¹ / ₂ L composition
R562	1-246-618	5.1Ω	±5% ERD14T	carbon	R902	1-206-056	120Ω $\pm 10\%$ 2W metal oxide
R563	1-246-631	18Ω	±5% ERD14T	carbon			
R564	1-246-655	180Ω	±5% ERD14T	carbon	VR301	1-221-998	500Ω-B adjustable (AGC)
					VR501	1-222-335	250kΩ-B variable (Brightness)
R601	1-246-642	51Ω	±5% ERD14T	carbon	VR502	1-222-337	3kΩ-C variable (Contrast)
R602	1-246-656	200Ω	±5% ERD14T	carbon	VR551	1-222-340	$5k\Omega$ -D variable (with SW) (Volume)
R603	1-246-697	$10 \mathrm{k}\Omega$	±5% ERD14T	carbon	VR601	1-222-184	1kΩ-B variable (Hor. Hold)
R604	1-246-718	$100 \mathrm{k}\Omega$	±5% ERD14T	carbon	VR701	1-222-336	2kΩ-B variable (Ver. Hold)
R605	1-246-669	680Ω		carbon	VR702	1-221-349	5kΩ-B adjustable (Ver. Linearity)
R606	1-246-647	82Ω	±5% ERD14T	carbon	VR703	1-221-349	5kΩ-B adjustable (Ver. Height)
R607	1-246-688	$4,300\Omega$	±5% ERD14T	carbon	VR801	1-221-351	600kΩ-B adjustable (Focus)
R608	1-246-685	$3,300\Omega$	±5% ERD14T	carbon			
R609	1-250-873	1kΩ	±5% RD12T	carbon		MISO	CELLANEOUS
R610	1-246-677	1,500Ω	±5% ERD14T	carbon			
R611	1-246-694	$7,500\Omega$	±5% ERD14T		DET	1-425-518	detector block
R613	1-246-667	560Ω	±5% ERD14T	carbon	DY	1-451-003-09	deflection yoke ass'y
R614	1-246-662	360Ω	±5% ERD14T	carbon	F901	1-532-118-12	fuse 1.6A
R615	1-246-664	430Ω	±5% ERD14T ±5% ERD14T	carbon carbon		1-501-118-11 1-502-100	telescopic antenna speaker
R616 R617	1-246-684 1-246-680	3kΩ 2kΩ	±5% ERD14T			1-506-108	SV-pin
KOI	1-240-060	ZKIL	25% ERD141	Carbon		1-507-166	jack, external antenna
R701	1-246-663	390Ω	±5% ERD14T	carbon		1-507-174-33	jack, earphone; twin
R702	1-246-688	4,300Ω	±5% ERD14T			1-507-901-12	jack nut
R703	1-246-677	1,500Ω	±5% ERD14T		1	1-508-156-41	power plug with switch
R704	1-246-629	15Ω	±5% ERD14T			1-526-084-21	socket, picture tube
R705	1-246-688	4,300Ω	±5% ERD14T			1-536-107	lug terminal board, 1-1P
R706	1-246-688	4,300Ω	±5% ERD14T	carbon		1-417-019-32	U-V separator ass'y
R707	1-246-696	$9,100\Omega$	±5% ERD14T	carbon		1-534-379-41	output cable, IF
R708	1-246-680	$2k\Omega$	±5% ERD14T	carbon		7-613-077-02	coaxial cable 1.5D-XV
R709	1-246-680	2kΩ	±5% ERD14T	carbon		8-731-105-10	picture tube (140CB4)
R710	1-246-695	$8,200\Omega$	±5% ERD14T	carbon			
	(1-246-678	$1,600\Omega$	±5% ERD14T	carbon			
* R711	1-246-679	$1,\!800\Omega$	±5% ERD14T	carbon		THE	NED BLOCK
	1-246-680	$2k\Omega$	±5% ERD14T			10	NER BLOCK
	1-246-681	$2,200\Omega$	±5% ERD14T				
R712	1-246-660	300Ω	±5% ERD14T			SEM	ICONDUCTORS
R713	1-207-018	3Ω	±5% RW¼RL		Q201		transistor SPS-1351
R714	1-207-018	3Ω	±5% RW1/4RI		Q202		transistor SPS-1353
R715	1-246-656	200Ω	±5% ERD14T		Q203		transistor SPS-1352
R7 16	1-246-702	15kΩ	±5% ERD14T	carbon		0017.0	UD TO ANGEODMERS
	1040	41	1 FOU EDD:		1 201		ND TRANSFORMERS
R801	1-246-673	1kΩ	±5% ERD14T		L201	1-409-192	IF trap coil
R803	1-246-649	100Ω	±5% ERD14T	Caroon	L202	1-409-186	IF trap coil
							*: to be selected


- 38 **-**

Ref. No.	Part No.	Descr	iption	Ref. No.	Part No.		Desc	ription	
L203	1-425-595	RF coil		C219	1-101-560	20pF	±	5% 50WV	ceramic
L204	1-425-596	RF coil		C220	1-102-988	4pF	±0.2	pF 50WV	ceramic
L205	1-425-597	RF coil		C221	1-102-988	4pF	±0.2	pF 50WV	ceramic
L207	1-403-544	IFT transformer		C222	1-102-143	2pF	±0.2	pF 50WV	ceramic
L208	1-425-339	coil, compensati	ng 43W	C223	1-101-560	20pF	±	5% 50WV	ceramic
L211	1-407-096	7μF, micro indu	ictor	C225	1-102-455	0.001 µF	±20	0% 50WV	ceramic
L213	1-421-210	choke coil		C226	1-102-144	25 pF	±:	5% 50WV	ceramic
L214	1-421-210	choke coil		C227	1-101-584	2pF	±0.2	pF 50WV	ceramic
L215	1-423-147	coil with core		C228	1-101-072	$0.01 \mu F$	±86	8% 50WV	ceramic
L216	1-423-149	coil with core		C230	1-102-078	0.0018µF			feed through
				C231	1-102-078	$0.0018 \mu F$			feed through
				C235	1-105-839-12	$0.033 \mu \mathrm{F}$	±20)% 50WV	mylar
	•	CAPACITORS							
C201	1-101-564	100pF ±5	% 50WV ceramic						
C202	1-101-561	30pF ±5	% 50WV ceramic			RESISTORS	3		
C204	1-101-559	15pF ±5	% 50WV ceramic	R203	1-244-462	360Ω	±5%	RD1∕8P	carbon
C205	1-101-561	30pF ±5	5% 50WV ceramic	R204	1-244-452	130Ω	±5%	RD1/8P	carbon
C206	1-101-561	30pF ±5	5% 50WV ceramic	R205	1-244-493	Ω 008, δ	±5%	RD1/8P	carbon
C207	1-101-587	1.3pF ±0.2p	F 50WV ceramic	R206	1-244-485	$3,300\Omega$	±5%	RD1/8P	carbon
C208	1-102-813	13pF ±5	5% 50WV ceramic	R207	1-244-473	1kΩ	±5%	RD1/8P	carbon
C210	1-101-072	$0.01 \mu F$ $\pm \frac{80}{20}$	3% 50WV ceramic	R208	1-244-487	$3,900\Omega$	±5%	RD1/8P	carbon
C212	1-101-559	15pF ±5	5% 50WV ceramic	R209	1-244-480	$2k\Omega$	±5%	RD1/8P	carbon
C213	1-101-865	22pF ±5	5% 50WV ceramic	R210	1-244-494	$7,500\Omega$	±5%	RD1/8P	carbon
C215	1-101-560	20pF ±5	5% 50WV ceramic	R211	1-244-485	$3,300\Omega$	±5%	RD1/8P	carbon
C216	1-101-564	100pF ±:	5% 50WV ceramic	R212	1-244-497	10kΩ	±5%	RD1/8P	carbon
C217	1-101-072	$0.01 \mu F$ $\pm \frac{80}{20}$	3% 50WV ceramic	R213	1-244-497	10kΩ	±5%	RD¹∕8P	carbon
C218	1-101-576	1.5 pF ±0.2	pF 50WV ceramic						

When ordering replacement parts, you should use PART NUMBER listed on the Parts List or shown in the EXPLODED VIEW. The reference number should not be used for ordering purposes.

Hardware Nomenclature -E - Retaining Ring (E Washer)..... PS - Pan Head Screw W - Washer SW - Spring Washer LW - Lock Washer K - Flat Countersunk Head Screw ❖ N - Nut - Example -RK- Oval Countersunk Head Screw - Type of Slit - Truss Head Screw ⊕ P 3x10 Length in mm (L) $R - Round Head Screw \dots$ —Diameter in mm (D) ¹ F - Flat Fillister Head Screw -Type of Head

TV-510U BATTERY PACK



SPECIFICATIONS

Final Discharge Time:

2 hours

Full Charge Time:

12 hours

Batteries:

EVEREADY No. 563


Dimensions:

8'' (W) $\times 6\frac{3}{8}''$ (D) $\times 2\frac{6}{8}''$ (H)


(204 mm × 161 mm × 71 mm)

Weight:

15 oz (400 g)



PACKING



SONY CORPORATION

COMPLETE SPARE PARTS LIST CHANGE NOTICE

MODEL TV-510U (USA & CANADA Model)

(Production change, errection, addition, deletion)

is done onto this parts list.

Replace the former copy with this new one. Refer to this parts list when you order the service parts.

SONY®

Complete Spare Parts List

Model TV-510U

U.S.A. MODEL
CANADA MODEL

"TMPORTANT"

When ordering parts, please do not fail to furnish us the following:

- 1. Part Number
- 2. Model Name
- 3. Description as mentioned in this parts list

We are now using EDPS (Electronic Data Processing System) in all the departments concerned, for procurement, inventory control, packing, warehousing, etc. Your orders are processed mainly from the PART NUMBERS referred by you. Incorrect part numbers, therefore, will result in incorrect parts shipment. To assure prompt shipment of correct parts, your cooperation will be appreciated.

NOTE:

Prices are subject to change without notice.

COMPLETE SPARE PARTS LIST FOR TV-510U

(Canada and USA Model)

OCTOBER, 1971

Part No.	Description	Unit <u>Price</u>
	I, MECHANICAL PARTS	
x-40147-01 - 1	Cabinet Ass'y, front	\$0.73
X-40147-02	Protector Ass'y	0.90
X-40147-03	Carrying Handle Ass'y	0.20
X-40147-04	Knob Ass'y, channel selector	0.17
X- 40147-05	Knob Ass'y, fine tuning	0.15
X-40147-06	UHF Dial Ass'y	0.09
X-40147- 0 7	Knob Ass'y, control (A)	0.12
X-40147-08	Knob Ass'y, control (B)'	0.04
X-40147-09	Bushing Ass'y, insulating	0.04
X-43020-07	Knob Ass'y, uhf dial	0.12
2-825-001	Spacer, transistor	0.01
4-003-346	Clamp, antenna	0.04
4-004-127	Cushion, picture tube	0.08
4-005-422	Grounding Spring	0.02
4-005-615	Cover. terminal	0.01
4-006-238-03	Screw, tuner mounting	0.01
4-006-255	Terminal Pin	0.01
4-008-361	Heat Sink, TO-1	0.02
4-009-536	SIF Shield Case, upper	0.02
♦ 4-015-728	SIF Shield Case upper	0.03
4-009-537	SIF Shield Case. lower	0.02
♦ 4-015-729	SIF Shield Case, lower	0.02
4-009-538	Fiber Shield Case	0.02
4-010-012	Cylindrical Shield, micro inductor	0.03
4-012-812	VIF Shield Case, upper	0.03
♦ 4-015-730	VIF Shield Case, upper	0.02
4-010-506	VIF Shield Case, lower	0.01

Note: The components indicated with the symbol • are used for the following sets;

USA Model; Serial No. 48001 and later CANADA Model; Serial No. 10201 and later

Part No.	Description	Unit <u>Price</u>
♦ 4-015-731	VIF Shield Case, lower	
4-011-434-31	Knob, control C	
4-014-731-01	Nameplate	W . U
4-014-732	Connecting Plate, battery case	
4-014-734 4-014-735	Bracket, picture tube mounting	
4-014-736	Cabinet, rear	•••
4-014-737	Shielder, heat	0.05
4-014-738	Chassis	0.30
4-014-739	Bracket, tuner mounting	0.07
4-014-740	Bracket, power plug mounting	- • - •
4-014-741	Heat Sink, deflection circuit board	
4-014-741	Shield Case, audio circuit board	0.02
4-014-743	Clamp, electrolytic capacitor mounting	
4-014-744	Bracket A, volume control mounting	0.01
4-014-745	Bracket B, volume control mounting	0.04
4-010-017-02	Bracket C, volume control mounting	
4-014-753	Caution Label, high voltageOrnamental Plate	0.01
4-014-754	Shield Plate	
	II. MOUNTING HARDWARES	(per 100)
7-682-125-01		
7-682-125-01 7-682-146-01	Screw, machine phill P 2 x 5	0.10/100
	Screw, machine phill P 2 x 5Screw, machine phill P 3 x 5	0.10/100 0.12/100
7-682-146-01	Screw, machine phill P 2 x 5 Screw, machine phill P 3 x 5 Screw, machine phill P 3 x 50	0.10/100 0.12/100 0.62/100
7-682-146-01 7-682-198-01	Screw, machine phill P 2 x 5 Screw, machine phill P 3 x 5 Screw, machine phill P 3 x 50 Screw, machine phill P 3 x 10	0.10/100 0.12/100 0.62/100 0.32/100
7-682-146-01 7-682-198-01 7-682-149-13 7-682-248-04 7-621-559-69	Screw, machine phill P 2 x 5 Screw, machine phill P 3 x 5 Screw, machine phill P 3 x 50 Screw, machine phill P 3 x 10	0.10/100 0.12/100 0.62/100 0.32/100 0.48/100
7-682-146-01 7-682-198-01 7-682-149-13 7-682-248-04 7-621-559-69 7-621-722-57	Screw, machine phill P 2 x 5	0.10/100 0.12/100 0.62/100 0.32/100 0.48/100 0.69/100
7-682-146-01 7-682-198-01 7-682-149-13 7-682-248-04 7-621-559-69 7-621-722-57 7-621-722-63	Screw, machine phill P 2 x 5	0.10/100 0.12/100 0.62/100 0.32/100 0.48/100 0.69/100 0.23/100
7-682-146-01 7-682-198-01 7-682-149-13 7-682-248-04 7-621-559-69 7-621-722-57 7-621-722-63 7-621-724-32	Screw, machine phill P 2 x 5	0.10/100 0.12/100 0.62/100 0.32/100 0.48/100 0.69/100 0.23/100 0.24/100
7-682-146-01 7-682-198-01 7-682-149-13 7-682-248-04 7-621-559-69 7-621-722-57 7-621-722-63 7-621-724-32 7-621-724-44	Screw, machine phill P 2 x 5 Screw, machine phill P 3 x 5 Screw, machine phill P 3 x 50 Screw, machine phill P 3 x 10 Screw, machine phill K 3 x 8 Screw, machine phill K 2.6 x 12 Screw, tapping phill BV 3 x 8 Screw, tapping phill BV 3 x 10 Screw, tapping phill R 4 x 8 Screw, tapping phill R 4 x 10	0.10/100 0.12/100 0.62/100 0.32/100 0.48/100 0.69/100 0.23/100
7-682-146-01 7-682-198-01 7-682-149-13 7-682-248-04 7-621-559-69 7-621-722-57 7-621-722-63 7-621-724-32 7-621-724-44 7-684-013-01	Screw, machine phill P 2 x 5	0.10/100 0.12/100 0.62/100 0.32/100 0.48/100 0.69/100 0.23/100 0.24/100 0.38/100
7-682-146-01 7-682-198-01 7-682-149-13 7-682-248-04 7-621-559-69 7-621-722-57 7-621-722-63 7-621-724-32 7-621-724-44 7-684-013-01 7-622-107-05	Screw, machine phill P 2 x 5	0.10/100 0.12/100 0.62/100 0.32/100 0.48/100 0.69/100 0.23/100 0.24/100 0.38/100 0.40/100
7-682-146-01 7-682-198-01 7-682-149-13 7-682-248-04 7-621-559-69 7-621-722-57 7-621-722-63 7-621-724-32 7-621-724-44 7-684-013-01 7-622-107-05 7-623-108-17	Screw, machine phill P 2 x 5	0.10/100 0.12/100 0.62/100 0.32/100 0.48/100 0.69/100 0.23/100 0.24/100 0.38/100 0.40/100 0.28/100 0.27/100 0.10/100
7-682-146-01 7-682-198-01 7-682-149-13 7-682-248-04 7-621-559-69 7-621-722-57 7-621-722-63 7-621-724-32 7-621-724-44 7-684-013-01 7-622-107-05 7-623-108-17 7-623-110-15	Screw, machine phill P 2 x 5	0.10/100 0.12/100 0.62/100 0.32/100 0.48/100 0.69/100 0.23/100 0.24/100 0.38/100 0.40/100 0.28/100 0.27/100
7-682-146-01 7-682-198-01 7-682-149-13 7-682-248-04 7-621-559-69 7-621-722-63 7-621-724-32 7-621-724-44 7-684-013-01 7-622-107-05 7-623-108-17 7-623-207-22	Screw, machine phill P 2 x 5	0.10/100 0.12/100 0.62/100 0.32/100 0.48/100 0.69/100 0.23/100 0.24/100 0.38/100 0.40/100 0.28/100 0.27/100 0.10/100
7-682-146-01 7-682-198-01 7-682-149-13 7-682-248-04 7-621-559-69 7-621-722-63 7-621-724-32 7-621-724-44 7-684-013-01 7-622-107-05 7-623-108-17 7-623-110-15 7-623-207-22 7-623-208-22	Screw, machine phill P 2 x 5	0.10/100 0.12/100 0.62/100 0.32/100 0.48/100 0.69/100 0.23/100 0.24/100 0.38/100 0.40/100 0.28/100 0.27/100 0.10/100 0.22/100 0.05/100 0.06/100
7-682-146-01 7-682-198-01 7-682-149-13 7-682-248-04 7-621-559-69 7-621-722-63 7-621-724-32 7-621-724-44 7-684-013-01 7-622-107-05 7-623-108-17 7-623-207-22	Screw, machine phill P 2 x 5	0.10/100 0.12/100 0.62/100 0.32/100 0.48/100 0.69/100 0.23/100 0.24/100 0.38/100 0.40/100 0.28/100 0.27/100 0.10/100 0.22/100 0.05/100

2/18 (TV-510U Canada and USA Model)

Ref. <u>No</u> .	Part No.	<u>Description</u>		Unit <u>Price</u>
Q701		Transistor,	2SC633A	\$0.14
Q702		Transistor,	2SB382	0.21
Q703		Transistor,	2SD29	0.42
Q801		Transistor,	2SB324	0.28
Q802		Transistor,	2SC756	0.42
D301		Diode,	1T261	0.05
D302		Diode,	1T22	0.05
♦ D302		Diode,	1T22A	0.05
D401		Diode,	1T243	0.07
◆ D401		Diode,	1T374	0.11
D402		Diode,	1T23	0.05
◆ D402				
D403		Diode,	1T23	0.05
◆ D403		<u></u>		
D501		Diode,	1T22A	0.05
D601		Diode,	1T22A	0.05
D602		Diode,	1T22A	0.05
D701		Diode,	1T22A	0.05
D702		Diode,	1T22A	0.05
D801		Diode,	HFSD1Z	0.12
D 8 02		Diode,	10D2	0.11
D803		Diode,	UFSD1A	0.21
D901		Diode,	10D2	0.11
D 902		Diode,	10D2	0.11
D903		Diode,	10D2	0.11
Th301	8-690-003	Thermistor,	S 90	0.03
Th 302	8-690-006	Thermistor,	\$1250	0.03
Th 551	8-691-001	Thermistor,	CS-120	0.06
IC401	8-759-101-60	IC,	μPC-16C	1.29

Ref. <u>No</u> .	Part No.	Description		Unit <u>Price</u>
		Coils		
L7	1-407-178	1 μΗ	micro inductor	\$0.04
L301 L302	1-409-160-31 1-409-160-21	41.25 MHz 47.25 MHz	trap coil	0.09
L303 L304	1-409-160-21 1-409-170	39.75 MHz 33.75 MHz	trap coil	0.09 0.12
L305	1-407-178	1 μΗ	micro inductor	0.04
♦ L305 L306	1-407-520 1-407-178	0.6 μH 1 μH	micro inductor	0.08 0.04
♦ 1306	1-407-520	0.6 µН	micro inductor	0.08
L307 ♦ L307	1-407-157 1-407-178	10 μH 1 μH	micro inductor	0.03 0.04
L308	1-407-184	3.3 µH	micro inductor	0.05
♦ L308	1-407-157	10 μH	micro inductor	0.03
L309 ◆L309	1-407-173 1-407-184	220 µН 3.3 µН	micro inductor micro inductor	0.03 0.05
L310	1-407-184	3.3 µH	micro inductor	0.05
◆L310 L311	1-407-178	- 1 μH	micro inductor	0.04
♦ L311	1-407-184	3.3 µH	micro inductor	0.05
L401	1-407-178	1 μΗ	micro inductor	0.04
L402	1-409-036	4.5 MHz 4.5 MHz	trap coil	0.10 0.11
♦ L402 L403	1-409-179 1-407-187	4.5 rm2 5.6 μH	micro inductor	0.04
♦ L403		-		0.02
L501	1-407-172	180 μΗ	micro inductor	0.03
L601	1-407-165	47 μΗ	micro inductor	0.03
L701	1-421-127	Choke Coil, ve	ertical output	0.34
L801	1-421-013-11	25 μΗ	filter inductor	0.04
L803	1-413-012-12	Coil, horizont	tal stabilizing	0.14
L901	1-421-150-12	Filter Choke C	Coil, power rectifier	0.36

Ref.	Part No.	Description	Unit <u>Price</u>					
Transformers								
Т302	1-403-701	Transformer, video i-f; VIFT-2	\$0.12					
T303	1-403-702	Transformer, video i-f; VIFT-3	0.12					
♦ T303	1-403-727	Transformer, video i-f; VIFT-3	0.12					
T401	1-403-348	Transformer, sound i-f; SIFT-1	0.12					
♦ T401	1-403-362	Transformer, sound i-f; SIFT-1	0.12					
T402	1-403-349	Transformer, sound i-f; SIFT-2	0.13					
♦ T402	1-403-361	Transformer, sound i-f; SIFT-2	0.12					
T403	1-403-313	Transformer, sound i-f; SIFT-3	0.27					
♦ T403	1-403-361	Transformer, sound i-f; SIFT-3	0.12					
T701	$\binom{1-435-008-12}{1-435-008-11}$	Transformer, vertical osc.; VBT	0.14					
	1-435-008-11	Transformer, vertical osc.; VBT	0.14					
T801	1-435-016-11	Transformer, horizontal osc.; HBT	0.16					
T802	1-437-004-11	Transformer, horizontal drive; HDT	0.21					
T803	1-453-625	High Voltage Cage Block; HOT	3.12					
T901	1-441-618	Transformer, power; PT	1.28					
		Capacitors						
C301	1-101-957	7 pF +0.5 pF 50 WV ceramic	0.02					
♦ C301	1-102-858	10 pF +0.5 pF 50 WV ceramic	0.02					
C302	1-101-969	5 pF +0.5 % 50 WV ceramic	0.03					
♦ C302	1-102-882	4 pF +0.25 pF 50 W ceramic	0.02					
C303	1-101-969	5 pF +0.5 % 50 WV ceramic	0.03					
C304	1-101-832	9 pF +0.2 pF 50 WV ceramic	0.01					
♦ C 304	1-102-856	5 pF ±0.5 pF 50 WV ceramic	0.03					
C305	1-101-583	60 pF +5 % 50 WV ceramic	0.02					
♦ C305	1-102-664	9 pF +0.5 pF 50 WV ceramic	0.02					
C306	1-101-057	80 pF ± 5 % 50 WV ceramic	0.02					
♦ C306	1-102-856	5 pF ±0.5 pF 50 WV ceramic	0.03					
C307	1-101-892	82 pF +5 % 50 WV ceramic	0.02					
♦ C307			-					
C308	1-101- 0 03	0.0047 µF +100 -0 % 50 WV ceramic	0.02					
♦ C308	1-102-863	82 pF +5 % 50 WV ceramic	0.03					
C309	1-101-003	0.0047 μF +100 -0 % 50 WV ceramic	0.02					
C310	1-101-961	12 pF +5 % 50 WV ceramic	0.02					
♦ C310	1-101-003	0.0047 μF +100 -0 % 50 WV ceramic	0.02					

Ref. <u>No</u> .	Part No.	Descriptio	<u>n</u>			Unit Price
C311	1-101-003	0.0047 µF	+100 -0 %	50 WV	ceramic	\$0.02
C312	1-101-455	$0.001~\mu F$	<u>+</u> 20 %	50 WV	ceramic	0.02
♦ C312	1-101-003	0.0047 μF	+100 -0 %	50 WV	ceramic	0.02
C313	1-101-003	0.0047 µF	+100 -0 %	50 WV	ceramic	0.02
◆ C313	1-102-959	22 pF	<u>+</u> 5 %	50 WV	ceramic	0.01
C314	1-101-961	12 pF	<u>+</u> 5 %	50 WV	ceramic	0.02
♦ C314	1-101 - 886	62 pF	<u>+</u> 5 %	50 WV	ceramic	0.01
C315	1-101-003	0.0047 μF	+100 -0 %	50 WV	ceramic	0.02
C316	1-101-003	0.0047 μF	+100 -0 %	50 WV	ceramic	0.02
C317	1-101-455	0.001 μF	<u>+</u> 20 %	50 WV	ceramic	0.02
♦ C317	1-101-003	0.0047 μF		50 WV	ceramic	0.02
C318	1-101-940	2.5 pF	<u>+</u> 10 %	50 WV	ceramic	0.02
♦ C318	1-102-959	22 pF	<u>+</u> 5 %	50 WV	ceramic	0.01
C319	1-101-003	0.0047 μF		50 WV	ceramic	0.02
♦ C319	1-102-965	39 pF	<u>+</u> 5 %	50 WV	ceramic	0.01
C320	1-121-398	10 μF	+100 -0 %	25 WV	electrolytic -	0.03
♦ C320	1-101-834	1.8 pF	± 0.2 pF	50 WV	ceramic	0.02
C321	1-101-003	0.0047 μF	+100 -0 %	50 WV	ceramic	0.02
C322		- .				
♦ C322	1-121-471	10 μF	+100 -10 %	16 WV	electrolytic -	0.04
C323	1-101-003	·	+100 -0 %	50 WV	ceramic	0.02
C324	1-101-587	1.3 pF	<u>+</u> 0.2 pF	50 WV	ceramic	0.03
♦ C324	1-101-003	0.0047 μF	+100 -0 %	50 WV	ceramic	0.02
C 32 5		-				
C326		-				
◆ *C326	1-101-587	1.3 pF	+0.2 pF	50 WV	ceramic	0.03
◆*C326	1-101-576	1.5 pF	± 0.2 pF	50 WV	ceramic	0.02
♦ *C326	1-101-834	1.8 pF	<u>+</u> 0.2 pF	50 WV	ceramic	0.02
♦ *C32 6	1-102-935	2 pF	± 0.25 pF	50 WV	ceramic	0.01
♦ *C326	1-101-574	2.5 pF	$\pm 0.2 \text{ pF}$	50 WV	ceramic	=
◆*C326	1-102-936	3 pF	<u>+</u> 0.25 pF	50 WV	ceramic	0.01
C327	1-101-955	5 pF	± 0.5 pF	50 WV	ceramic	0.02
◆ C327		.			_	
C328	1-101-003	0.0047 μF	+100 -0 %	50 WV	ceramic	0.02
◆ C328		-				
C329	1-121-402	33 μF	+100 -0 %	10 WV	electrolytic -	0.05
◆ C329	1-101-003	0.0047 μF		50 WV	ceramic	0.02
C330	1-101-006	0.047 μF	+100 -0 %	50 WV	ceramic	0.03
♦ C330	1-121-402	33 μF	+100 -10 %	16 WV	electrolytic -	0.05
C331	1-127-023	1 μF	<u>+</u> 20 %	10 WV	electrolytic	
♦ C331	1-102-942	5 pF	<u>+</u> 0.5 pF	50 WV	(alox)ceramic	0.06 0.01

Ref.						Unit
No.	Part No.	Description	on			Price
0000						
C332	1-105-669-12	0.0047 µF	±10 %	50 WV	my1ar	•
◆ C332	1-101-004	0.01 μF	+100 -0 %	50 WV	ceramic	0.01
C333	1-127-024	2.2 μF	<u>+</u> 20 %	10 WV	electrolytic	
C333	1 101 401	220 17	1100 10 %	16 177	(alox)	0.07
C333	1-121-421 1-101-958	220 μF	+100 -10 %	16 WV	electrolytic -	0.08
◆ C334	1-101-936	8 pF 0.01 μF	±0.5 pF	50 WV	ceramic	0.01
* C334	1-101-837	0.01 µr	+100 -0 %	50 WV	ceramic	0.01
*C335	1-101-537	0.5 pr 0.8 pF	+0.2 pF +0.2 pF	50 WV 50 WV	ceramic	0.02
*C335	1-101-163	1 pF	±0.2 pr +20 %	50 WV	ceramic	0.02
◆ C335	1101103	r pr	<u>+</u> 20 %	20 WV	ceramic	0.02
C336		_				
♦ C336	1-127-023	1 μF	+20 %	10 WV	electrolytic	
•	1 14, 013			10 ///	(alox)	0.06
C337	1-127-022	0.47 µF	+20 %	10 WV	electrolytic	0.00
		, , , , , , , , , , , , , , , , , , ,		10	(alox)	0.06
♦ C337	1-105-709-12	0.0047 µF	+10 %	100 WV	mylar	0.02
C338		-			, 2012	0.02
♦ C338	1-127-024	2.2 µF	+20 %	10 WV	electrolytic	
		-	-		(alox)	0.07
C339		-			, ,	
♦ C339	1-127-022	$0.47 \mu F$	<u>+</u> 20 %	10 WV	electrolytic	
					(alox)	0.06
C340		-				
♦ C 340	1-102-978	220 pF	<u>+</u> 5 %	50 WV	ceramic	0.02
C341	1-101-455	$0.001 \mu F$	<u>+</u> 20 %	50 WV	ceramic	0.02
◆ C341	1-101-003	0.0047 μF	+100 -0 %	50 WV	ceramic	0.02
C342	1-101-969	5 pF	<u>+</u> 0.5 pF	50 WV	ceramic	0.03
♦ C342	1-101-003	0.0047 μF	+100 -0 %	50 WV	ceramic	0.02
C401	1-103-610	240 pF	<u>+</u> 5 %	50 WV	polystyrene	0.03
♦ C401	1-103-663	330 pF	+10 %	50 WV	polystyrene	0.03
C402	1-103-663	330 pF	+10 %	50 WV	polystyrene	0.03
♦ C402		_	•		1 -5 -5 -5	
C403	1-101-896	100 pF	<u>+</u> 5 %	50 WV	ceramic	0.02
♦ C403	1-101-004	0.01 µF	+100 -0 %	50 WV	ceramic	0.01
C404	1-101-004	0.01 µF	+100 -0 %	50 WV	ceramic	0.01
C405	1-101-956	6 pF	+0.5 pF	50 WV	ceramic	0.02
♦ C405	1-101-004	0.01 µF	+100 -0 %	50 WV	ceramic	0.01
C406	1-101-004	0.01 µF	+100 -0 %	50 WV	ceramic	0.01
C407		-				
♦ C407	1-102-100	0.0022 µF	<u>+</u> 20 %	50 WV	ceramic	0.02

8/18 (TV-510U Canada and USA Model)

	Ref. <u>No</u> .	Part No.	Descriptio	<u>on</u>			Unit Price
	C408	1-101-004	0.01 μF	+100 -0 %	50 WV	ceramic	\$0.01
•	C408	1-101-118	$0.01~\mu F$	<u>+</u> 20 %	50 WV	ceramic	0.02
	C409	1-101-455	$0.001~\mu F$	<u>+</u> 20 %	50 WV	ceramic	0.02
*	C409	1-102-678	100 pF	±5 %	50 WV	ceramic	0.03
_	C410	1-101-958	8 pF	<u>+</u> 5 pF	50 WV	ceramic	0.01
•	C410		-				
	C411	1-101-004	0.01 µF	+100 -0 %	50 WV	ceramic	0.01
	C412	1-101-006	0.04 µF	+100 -0 %	50 WV	ceramic	0.03
•	C412	1-121-471	10 μF	+100 -10 %	16 WV	electrolytic -	0.04
	C413	1-101-115	30 pF	+5 %	50 WV	ceramic	0.02
•	C413	1-101-004	0.01 µF	+100 -0 %	50 WV	ceramic	0.01
	C414	1-101-571	140 pF	±5 %	50 WV	ceramic	0.04
•	C414	1-101-004	0.01 μF	+100 -0 %	50 WV	ceramic	0.01
	C415	1-101-423	500 pF	<u>+</u> 20 %	50 WV	ceramic	0.02
•	C415	1-101-896	100 pF	±5 %	50 WV	ceramic	0.02
	C416	1-101-423	500 pF	<u>+</u> 20 %	50 WV	ceramic	0.02
•	C416	1 101 200	10 .7	.100 0 %	0 E 181		0.03
	C417	1-121-398	10 μF	+100 -0 %	25 WV	ceramic	0.03
•	C417	1 101 110	0.01.45	+20 %	50 WV	ceramic	0.02
	C418	1-101-118	$0.01~\mu F$	+20 %	30 WV	ceramic	0.02
•	C418	1 101 110	0.01	120 %	SO UNI	ceramic	0.02
	C419	1-101-118	0.01 µF	<u>+</u> 20 %	50 WV	ceramic	0.02
•	C419	1-101-002	0.002 μF	+100 -0 %	50 WV	ceramic	0.02
_	C420	1-101-002	0.002 μr	+100 -0 %	JO WV	ceramic	0.02
•	C420		_				
	C421 C422	1-101-006	0.047 μF	+100 -0 %	50 WV	ceramic	0.03
4	C422	1-101-000	0.047 μΓ	+100 -0 %	30 WV	Celamic	0.03
	C423	1-101-003	0 0047 nF	+100 -0 %	50 WV	ceramic	0.02
_	C423	1-101-005	-	7100 0 %	30	o o z q z o	
	C424	1-121-358	220 µF	+100 -0 %	16 WV	electrolytic -	0.07
4	C424 ►C424	1-121-550		1100 0 %	10 ""	010001019010	0.01
	7 0 4 2 4						
	C501	1-121-469	10 µF	+100 -0 %	10 WV	electrolytic -	0.03
	C 502	1-102-834	390 pF	±10 %	50 WV	ceramic	0.02
	C503	1-113-124	0,2 μF	+10 %	150 WV	paper	0.09
	C504	1-121-246	4.7 μF	+100 -0 %	160 WV	electrolytic -	0.06
	C 5 0 5	1-113-122	0.05 µF	+20 %	500 WV	paper	0.07
	C506	1-121-415	100 μF	+100 -0 %	16 WV	electrolytic -	0.06
	C507	1-121-398	10 μF	+100 -0 %	25 WV	electrolytic -	0.03
	C551	1-121-398	10 μF	+100 -0 %	25 WV	electrolytic -	0.03

9/18 (TV-510U Canada and USA Model)

Ref.	Part No.	Description	<u>on</u>			Unit Price
C552	1-121-421	220 µF	+100 -0 %	16 WV	electrolytic -	\$0.08
C553	1-121-402	33 μF	+100 -0 %	10 WV	electrolytic -	0.05
C554	1-121-421	220 µF	+100 -0 %	16 WV	electrolytic -	0.08
C555	1-121-409	47 µF	+100 -0 %	16 WV	electrolytic -	0.04
C556	1-105-717-12	$0.022 \mu F$	+10 %	100 WV	mylar	0.03
C557	1-105-717-12	0.022 µF	+10 %	100 WV	mylar	0.03
C558	1-127-019	0.1 µF	+20 %	10 WV	electrolytic	••••
		·			(alox)	0.06
C602	1-127-094	1 μF	<u>+</u> 20 %	25 WV	electrolytic	
					(alox)	0.08
C603	1-105-715-12	0.015 μF	<u>+</u> 10 %	100 WV	mylar	0.04
C604	1-105-711-12	0.0068 µF	±10 %	100 WV	mylar	0.03
C605	1-105-721-12	0.047 µF	<u>+</u> 10 %	100 WV	mylar	0.05
C606	1-121-415	100 μF	+100 -0 %	16 WV	electrolytic -	0 .0 6
C607	1-121-396	4.7 μF	+100 -0 %	50 WV	electrolytic -	0.04
C608	1-127-091	0.22 μF	<u>+</u> 20 %	25 WV	electrolytic	
					(alox)	0.06
C609	1-105-721-12	0.047 μF	<u>+</u> 10 %	100 WV	mylar	0.05
C610	1-105-717-12	$0.022 \mu F$	<u>+</u> 10 %	100 WV	mylar	0.03
C611	1-121-393	3.3 μF	+100 -0 %	50 WV	electrolytic -	0.03
C701	1-127-232	4.7 μF	<u>+</u> 20 %	25 WV	electrolytic	
0700					(alox)	0.16
C702	1-131-116	10 μF	<u>+</u> 20 %	16 WV	electrolytic -	0.35
C703	1-121-398	10 μF	+100 -0 %	50 WV	electrolytic -	0.03
C704	1-127-231	3.3 μF	<u>+</u> 20 %	25 WV	electrolytic	
					(alox)	0.16
C705	1-121-420	220 μF	+100 -0 %	10 WV	electrolytic -	0.07
C706	1-121-426	470 µF	+100 -0 %	16 WV	electrolytic -	
C707	1-105-727-12	0.15 μF	±10 %	100 WV	mylar	0.13
C709	1-105-713-12	0.01 μF	<u>+</u> 10 %	100 WV	mylar	0.03
C801	1-105-715-12	$0.015 \mu F$	<u>+</u> 10 %	100 WV	mylar	0.04
C802	1-105-723-12	0.068 µF		100 WV	mylar	0.06
C803	1-105-729-12	0.22 µF	<u>+</u> 10 %	100 WV	mylar	0.10
*C804	1-105-721-12	$0.047 \mu F$	<u>+</u> 10 %	100 WV	mylar	0.05
*C804	1-105-725-12	$0.1 \mu F$	<u>+</u> 10 %	100 WV	mylar	0.07
*C804	1-105-727-12	0.15 μF	<u>+</u> 10 %	100 WV	mylar	0.13
*C804	1-105-729-12	0.22 µF	<u>+</u> 10 %	100 WV	mylar	0.10
C805	1-105-725-12	0.1 μF	<u>+</u> 10 %	100 WV	mylar	0.07

^{*} Mark to be selected.

Ref.	Part No.	Descripti	on			Unit Price
C806	1-121-421	220 µF	+100 -0 %	16 WV	electrolytic -	\$0.08
C807	1-105-292-12	$0.055 \mu F$	<u>+</u> 10 %	250 WV	mylar	0.10
C808	1-105-274-12	0.01 μF+0	.005 μF	200 WV	mylar	0.12
C809	1-105-753-12	0.01 µF	<u>+</u> 10 %	100 WV	mylar	0.04
C811	1-113-122	$0.05 \mu F$	<u>+</u> 20 %	500 WV	paper	0.07
C812	1-113-122	$0.05~\mu F$	<u>+</u> 20 %	500 WV	paper	0.07
C813	1-113-122	0.05 µF	±20 %	500 WV	paper	0.07
C814	1-113-122	$0.05 \mu F$	<u>+</u> 20 %	500 WV	paper	0.07
C818	1-101-845	1000 pF	+100 -0 %	500 WV	ceramic	0.02
C819	1-101-455	1000 pF	<u>+</u> 20 %	50 WV	ceramic	0.02
C901	1-121-555	4000 µF	+100 -15 %	15 WV	electrolytic -	0.38
C902	1-119-106	100 µF	<u>+</u> 20 %	16 WV	electrolytic -	0.04
C903	1-121-555	4000 μF	+100 -15 %	15 WV	electrolytic -	0.38
C904	1-101-003	$0.005 \mu F$	+100 -0 %	50 WV	ceramic	0.02
C905	1-101-003	0.005 μF	+100 -0 %	50 WV	ceramic	0.02
		Resist	ors			
			stors are <u>+</u> 5 therwise spec		, carbon	
R301	1-248-629	15 Ω	<u>+</u> 10 %	ERD14V -		0.02
R301	1-246-627	12 Ω				0.02
R 302 ♦ R 302	1-248-629	15 Ω	<u>+</u> 10 %	ERD14V		0.02

R301	1-248-629	15 Ω	<u>+</u> 10 %	ERD14V	- 0.02
♦ R301	1-246-627	12 Ω			- 0.02
R 302		-			
♦ R302	1-248-629	15 Ω	<u>+</u> 10 %	ERD14V	- 0.02
R303	1-248-627	12 Ω		ERD14V	- 0.02
♦ R303	1-246-649	100 Ω			- 0.02
R304	1-248-649	100 Ω	<u>+</u> 10 %	ERD14V	- 0.02
♠ R304	1-246-669	680 Ω -			- 0.02
R305	1-248-659	270 Ω	<u>+</u> 10 %	ERD14V	- 0.02
♠ R305	1-246-705	22 kΩ -			- 0.02
R306	1-248-657	220 Ω	<u>+</u> 10 %	ERD14V	- 0.02
▲ R306	1-246-659	270 Ω -			- 0.02
R307	1-248-665	470 Ω	<u>+</u> 10 %	ERD14V	- 0.02
◆R307	1-246-657	220 Ω -			- 0.02
R308	1-248-656	200 Ω	<u>+</u> 10 %	ERD14V	- 0.02
♦ R308	1-246-657	220 Ω -			- 0.02
R309	1-248-657	220 Ω	<u>+</u> 10 %	ERD14V	- 0.02
♠ R309	1-246-663	390 Ω -			- 0.02
R310	1-248-659	270 Ω	<u>+</u> 10 %	ERD 14V	- 0.02
♦R310	1-246-705	22 kΩ -			- 0.02

Ref.					Unit
No.	Part No.	Descripti	on		<u>Price</u>
R311	1-248-658	240 Ω	<u>+</u> 10 %	ERD14V	\$0 02
♠ R311	1-246-659	270 Ω			0.02
R312	1-248-653	150 Ω	+10 %	ERD14V	0.02
♦ R312	1-246-696	9100 Ω			0.02
R313	1-248-696	9100 Ω	+10 %	ERD14V	0.02
♦ R313	1-246-675	1200 Ω			0.02
R314	1-248-675	1200 Ω	<u>+</u> 10 %	ERD14V	0.02
♦ R314	1-246-651	120 Ω			0.02
R315	1-248-651	120 Ω	<u>+</u> 10 %	ERD14V	0.02
♦ R315	1-246-659	270 Ω			0.02
R316	1-246-653				
♦ R316	1-246-646				
R317	1-248-646	75 Ω	±10 %	ERD14V	0.02
◆ R317	1-246-680				
R318	1-248-680	2 kΩ	<u>+</u> 10 %	ERD14V	0.02
♦ R318	1-246-655				
R319	1-248-655	180 Ω	<u>+</u> 10 %	ERD14V	0.02
◆ R319	1-246-690				0.02
R320	1-248-690	5100 Ω	<u>+</u> 10 %	ERD14V	0.02
◆ R320	1-246-682				O . O .
R321	1-248-681			ERD14V	
◆ R321	1-246-671				0.02
R322	1-248-671		<u>+</u> 10 %	ERD14V	• • • •
♠ R322	1-244-634	24 Ω		RD1/4CH	
R323	1-248-687		<u>+10 %</u>	ERD14V	
◆ R323		300 Ω	±10 %		
R324 ◆ R324	1-248-665	470 Ω		ERD14V	
R325	1-246-668 1-246-677				
	1-248-706				
	1-248-707	24 kΩ		ERD14VERD14V	
1000	1-248-707	27 kΩ 30 kΩ		ERD14V	
	1-248-710	36 kΩ		ERD14V	
*R326	1-248-710	39 kΩ		ERD14V	
*R326	1-248-712	43 kΩ		ERD14V	
*R326	1-248-713	43 kΩ 47 kΩ		ERD14V	0.02
*R326	1-248-714	51 kΩ		ERD14V	
*R326	1-248-715	56 kΩ		ERD14V	
♦ R326	1-246- 6 66	510 Ω		EKD144	
R327	1-248-700	13 kΩ		ERD14V	V.V.
◆*R327	1-246-706	24 kΩ		EW144	
★ *R327	1-246-707	27 kΩ		~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~	0.02
					0.02

12/18 (TV-510U Canada and USA Model)

Ref.				Unit
No.	Part No.	Description		<u>Price</u>
♦ *R327	1-246-708	30 kΩ		\$0.02
♦ *R327	1-246-709	33 kΩ		0.02
♦ *R327	1-246-710	36 kΩ		0.02
◆ *R327	1-246-711	39 kΩ		0.02
♦ *R327	1-246-712	43 kΩ		0.02
♦ *R327	1-246-713	47 kΩ		0.02
◆*R327	1-246-714	51 kΩ		0.02
◆*R327	1-246-715	56 kΩ		0.02
R328	1-248-655	180 Ω +10 %		0.02
♦ R328	1-246-700	13 kΩ		0.02
R329	1-248-665	470 Ω <u>+</u> 10 %	ERD14V	0.02
◆ R329	1-246-666	510 Ω		0.02
R330	1-248-683	2700 Ω	ERD14V	
◆ R330	1-248-655	180 Ω	ERD 14V	0.02
R331	1-248-671	820 Ω +10 %	ERD14V	
◆ R331	1-248-657	220 Ω	ERD14V	0.02
R332	1-248-657	220 Ω	ERD14V	0.02
◆ R332	1-246-657	220 Ω		0.02
*R333	1-248-703	18 kΩ	ERD14V	0.02
*R333	1-248-704	20 kΩ	ERD 14V	0.02
*R333	1-248-705	22 kΩ	ERD14V	
*R333	1-248-706	24 kΩ	ERD14V	0.02
◆*R333	1-246-701	15 kΩ		0.02
◆*R333	1-246-702	16 kΩ		0.02
◆*R333	1-246-703	18 kΩ		0.02
◆*R333	1-246-704	20 kΩ		- 0.02
◆*R333	1-246-705	22 kΩ		- 0.02
◆*R333	1-246-706	24 kΩ		- 0.02
R334	1-248-666	510 Ω	ERD14V	- 0.02
◆ R334	1-246-680	2700 Ω		- 0.02
R335	1-248-666	510 Ω	ERD14V	- 0.02
♦ R335	1-246-671	820 Ω		- 0.02
R336	-	-		
♦ R336	1-246-679	1800 Ω		- 0.02
- 105	1 2/8 (57	220 0	ERD14V	- 0.02
R401	1-248-657	220 Ω 75 Ω		- 0.02
♦ R401	1-246-646		ERD14V	- 0.02
R402	1-248-664	430 Ω		- 0.02
♦ R402	1-246-664	430 Ω 24 kΩ ±10 %	ERD14V	- 0.02
R403	1-248-706	330 Ω	MANU A 17	- 0.02
◆ R403	1-246-661	3600 Ω ±10 %	ERD14V	- 0.02
R404	1-248-686			- 0.02
♦ R404	1-246-649	100 Ω		

* Mark to be selected.

Ref.					Umit
No.	Part No.	Descripti	ion		Unit
NO.	Idic No.	Descripti	.011		Price
R405	1-248-673	1 kΩ	+10 %	ERD14V	\$0.02
◆ R405	1-246-687	3900 Ω			0.02
R406	1-248-649	100 Ω	+10 %	ERD14V	0.02
♦ R406	1-248-715	56 kΩ			0.02
*R407	1-203-892	3600 Ω		RD1/16L	0.02
*R407	1-203-497	3900 Ω		RD1/16L	0.02
*R407	1-203-185	4700 Ω		RD1/16L	0.02
*R407	1-204-345	5100 Ω		RD1/16L	0.02
*R407	1-203-186	5600 Ω		RD1/16L	0.02
*R407	1-203-187	6800 Ω		RD1/16L	0.02
*R407	1-203-189	8200 Ω		RD1/16L	0.02
*R407	1-203-190	10 kΩ		RD1/16L	0.02
♦ R407	1-246-673	1 kΩ			0.02
R408	1-248-694	7500 Ω	+10 %	ERD14V	0.02
◆ R408		-			
R409	1-248-685	3300 Ω	+10 %	ERD14V	0.02
♦ R409	1-248-632	20 Ω	-	ERD14V	0.02
R410	1-248-670	750 Ω	+10 %	ERD14V	0.02
♦ R410			•		
R411	1-248-673	1 kΩ	+10 %	ERD14V	0.02
♦ R411		-			
R412	1-204-345	51 0 0 Ω		RD1/16L	0.02
♦ R412		· -			
R413	1-248-649	100 Ω	+10 %	ERD14V	0.02
♦ R413					
R414	1-248-675	1200 Ω		ERD14V	0.02
◆R414		_			
R415	1-248-675	1200 Ω		ERD14V	0.02
♦ R415		-			
R416	1-248-685	3300 Ω		ERD14V	0.02
◆R416		_			
R417	1-248-685	3300 Ω		ERD14V	0.02
◆R417		• 💂			
R418	1-248-641	47 Ω	+10 %	ERD14V	0.02
♦R418		•••			
R419	1-248-715	56 kΩ	+10 %	ERD14V	0.02
♦R419					
R420	1-248-673	1 kΩ	+10 %	ERD14V	0.02
♦ R420	-	-	- · · · · · · · · · · · · · · · · · · ·		
¥ (m ×				•	
R501	1-246-697	10 kΩ			0.02
*R502	1-246-712	43 kΩ			0.02
	,	. =			

14/18 (TV-510U Canada and USA Mode1)

Ref.			Unit
No.	Part No.	Description	<u>Price</u>
*R502	1-246-713	47 kΩ	\$0.02
*R502	1-246-714	51 kΩ	0.02
*R502	1-246-715	56 kΩ	0.02
*R502	1-246-716	62 kΩ	0.02
*R502	1-246-717	68 kΩ	0.02
R503	1-246-651	120 Ω	0.02
R504	1-246-690	5100 Ω	0.02
R506	1-246-725	150 kΩ	0.02
R507	1-246-679	1800 Ω	0.02
R509	1-246-714	51 kΩ	0.02
R551	1-246-697	10 kΩ	0.02
R552	1-246-697	10 kΩ	0.02
R553	1-246-679	1800 Ω	0.02
R554	1-246-612	3 Ω	0.02
R555	1-246-673	6800 Ω	0.02
R556	1-246-675	1200 Ω	0.02
R557	1-246-641	47 Ω	0.02
R558	1-246-655	180 Ω	0.02
R559	1-246-659	270 Ω	0.02
R560	1-246-675	1200 Ω	0.02
R561	1-246-612	3 Ω	0.02
R562	1-246-618	5.1 Ω	0.02
R563	1-246-631	18 Ω	0.02
R564	1-246-655	180 Ω	0.02
R601	1-246-642	51 Ω	0.02
R602	1-246-656	200 Ω	0.02
R603	1-246-697	10 kΩ	0.02
R604	1-246-718	100 kΩ	0.02
R605	1-246-669	680 Ω	0.02
R606	1-246-647	82 Ω	0.02
R607	1-246-688	4300 Ω	0.02
R608	1-246-685	3300 Ω	0.02
R609	1-250-873	1 kΩ RD12T	0.02
R610	1-246-677	1500 Ω	0.02
R611	1-246-694	7500 Ω	0.02
R613	1-246-667	560 Ω	0.02
R614	1-246-662	360 Ω	0.02
R615	1-246-664	430 Ω	0.02
R616	1-246-684	3 kΩ	0.02
R617	1-246-680	2 kΩ	0.02

^{*} Mark to be selected.

Ref.			Unit
No.	Part No.	Description	Price
n 701	1 2/6 662	200.0	<u></u>
R 701 R 702	1-246-663	390 Ω	\$0.02
	1-246-688	4300 Ω	0.02
R703 R704	1-246-677	1500 Ω	0.02
	1-246-629	15 Ω	0.02
R705	1-246-688	4300 Ω	0.02
R706 R707	1-246-688	4300 Ω	0.02
	1-246-696	9100 Ω	0.02
R708	1-246-680	2 kΩ	0.02
R709	1-246-680	2 kΩ	0.02
R710	1-246-695	8200 Ω	0.02
*R711	1-246-678	1600 Ω	0.02
*R711	1-246-679	1800 Ω	- 0.02
*R711	1-246-680	2 kΩ	0.02
*R711	1-246-681	2200 Ω	0.02
R712	1-246- 6 60	300 Ω	0.02
R713	1-207-018	3 Ω RW1/4RL wire wound	0.01
R714	1-207-018	3 Ω RW1/4RL wire wound	0.01
R715	1-246-656	200 Ω	0.02
R716	1-246-702	15 kΩ	0.02
R801	1-246-673	1 kΩ	0.02
R803	1-246-649	100 Ω	0.02
R804	1-246-662	360 Ω	0.02
R806	1-246-697	10 kΩ	0.02
R807	1-246-691	5600 Ω	0.02
R808	1-246-694	7500 Ω	0.02
R811	1-202-621	100 k Ω \pm 10 % RC1/2, composition	0.02
R812	1-202-621	100 k Ω \pm 10 % RC1/2, composition	0.02
R813	1-202-649	1.5 M Ω ± 10 % RC1/2, composition	0.02
R814	1-246-732	300 kΩ	0.02
R901	1-201-676	750 k Ω +10 % RC1/2L, composition	0.02
R902	1-206-056	120 Ω ± 10 % 2 W, metal oxide	0.04

^{*} Mark to be selected.

Ref.	Part No.	Description	Unit <u>Price</u>
VR301 VR301	1-221-998 1-222-805	500 Ω -B, adjustable (AGC)	\$0.14 0.12
VR501 VR502 VR551	1-222-335 1-222-337 1-222-340	250 kΩ-B, variable (Brightness)3 kΩ-C, variable (Contrast)5 kΩ-D, variable (with SW) (Volume)	0.11 0.13 0.33
VR601	1-222-184	1 k Ω -B, variable (Hor. Hold)	0.14
VR701 VR702 VR703 VR801	1-222-336 1-221-349 1-221-349	2 k Ω -B, variable (Ver. Hold)5 k Ω -B, adjustable (Ver. Linearity)	0.13 0.09 0.09
		<u>Miscellaneous</u>	
DET	1-425-518	Detector Block	0.13
DET	1-425-636	Detector Block	0.15 1.75
DY	1-451-003-09	Deflection Yoke Ass'yFuse, 1.6 A	0.06
F901	1-532-118-12 1-501-118-11	Telescopic Antenna	0.92
	1-502-100	Speaker	0.52
	1-506-108	SV-pin	0.01
	1-507-166	Jack, external antenna	0.16
	1-507-174-33	Jack, earphone, twin	0.10
	1-507-901-12	Jack Nut	0.01
	1-508-156-41	Power Plug with Switch	0.24
	1-526-084-21	Socket, picture tube	0.37
	1-536-107	Lug Terminal Board, 1-1 P U-V Separator Ass'y	0.62
	1-417-019-32	Output Cable, IF	0.02
	1-534-379-41 8-731-105-10	Picture Tube (140CB4)	8.03

Part No.	Description	Unit <u>Price</u>
	IV. CARTON & ACCESSORIES	
4-014-747-01	Packing Carton	\$0.19
4-014-749	Cushion	0.10
4-014-750	Polyethylene Bag, cabinet	0.09
3-813-651	Color Label	0.01
X-44910-02-1	Warranty Card Ass'y	0.08
X-40147-11-1	Card Ass'y	0.06
X-44900-03	Polishing Cloth in Polyethylene Bag	0.03
4-495-257-11	Instruction Manual	0.08
4-490-014-10	Service Station List	0.03
4-002-839	IBM Card	0.01
1-504-034-22	Earphone (ME-20A)	0.14
1-534-519-17	Cord, power supply	0.38

18/18 (TV-510U Canada and USA Model) (TV-5-5R)

COMPLETE SPARE PARTS LIST FOR BP-21

OCTOBER, 1971

		Unit
Part No.	<u>Description</u>	<u>Price</u>
X-20411-03	Terminal Board Ass'y, left	\$0.10
x- 20411-04	Terminal Board Ass'v. right	0.10
X-20765-01	Battery Case Ass'v. upper	0.57
x-20765-02	Battery Case Ass'y, lower	0.52
Y-44014-32-1	VCP-1W	0.93
1-534-439-62	Cord, 4 P power supply	0.21
2-076-511-01	Screw, mounting case	0.14
2-076-512	Namenlate	0.07
2-076-513	Special Screw	0.07
2-076-514-01	Packing Carton	0.12
2-076-515	Master Carton	0.19
2-076-516	Polyethylene Bag	0.05
2-076-517	Cushion	0.05
2-076-518	Instruction Label	0.02
3-790-913-11	Instruction Manual	0.02
3-793-183	Inspection Tag	0.01
7-624-108-01	Retainer E-4	0.50/100
7-633-110-41	Clamp, power supply cord	0.05